



# Table of Contents

<b>Mounting and Powering the Platinum100</b> .....	<b>4</b>
Mounting Instructions .....	4
Power Connection .....	4
<b>Wake-Up Sequence</b> .....	<b>5</b>
<b>Receiving Alerts</b> .....	<b>6-9</b>
Radar Alert Sequence .....	6
Laser Alert Sequence .....	7
Laser Defuser Compatible .....	7
Laser Defuser Settings .....	7-8
Manual Laser Defuser Shutdown .....	8
Alerts from Non-Police Signals .....	8
K-Band Filter .....	8
Traffic Sensor Filter .....	9
MultiRadar (MRCD/CT) Photo Radar .....	9
Auto Volume .....	9
<b>OLED Display Overview</b> .....	<b>10-12</b>
Display Color .....	10
Display Mode and Alert Options .....	10-11
Dim Settings .....	12
<b>Special Features</b> .....	<b>13-20</b>
Highway City Filter Auto .....	13
K-Band Narrow Wide Extended .....	13-14
Ka-Band Narrow Wide .....	14
Ka-Band Filter .....	14
Quiet Ride .....	14-15
Mute Functions .....	15
<b>Platinum 100 Overview</b> .....	<b>16-17</b>
Mark to Mute .....	18
Mark to Alert .....	19-20
Speed Monitor .....	20
<b>Customizable Settings</b> .....	<b>21-23</b>
<b>Add-On Options</b> .....	<b>24</b>
<b>Wireless Remote Control Functions</b> .....	<b>25</b>
<b>Troubleshooting Guide</b> .....	<b>26</b>
<b>Warranty/Guarantees</b> .....	<b>27</b>
<b>Our Promise</b> .....	<b>29</b>

# Mounting and Powering the Platinum 100

## Mounting Instructions


To help ensure that your K40 functions properly and offers maximum protection, please follow these mounting instructions:

1. **Clean** the area of the windshield where the K40 will be mounted.\*
2. **Attach** the supplied Windshield Mount near the center of your vehicle's windshield by latching it firmly with the tension lever.
  - a. Slide unit onto the bracket until you hear a "click" to complete the mounting.
  - b. Once mounted, the bracket can be leveled by adjusting the control dial.
  - c. Do not mount behind windshield wipers or any other metal obstructions.

**\*IMPORTANT NOTE:** *Some windshields include a metallic coating that can significantly affect reception of radar signals. Consult with your dealer or check your vehicle's owner's manual to determine if your windshield has such a coating.*

## Power Connection

The K40 comes with two power cords: one 3.5' coiled cord and one 9.5' straight cord that can be used for hardwire installation. You can use either cord based on your visual preference and vehicle power outlet locations.

1. Plug the small end of the supplied Power Cord into the Power Input Jack on the right side of the Platinum100.
2. Plug the large end of the Power Cord into your vehicle's 12V outlet.
3. Power on by pressing and releasing the  button.

## Wake-Up Sequence

(using factory default settings)

Your K40 will be ready for use following this automatic Wake-Up sequence:

**Wake-Up Sequence** – The Platinum100 will announce and display “K40 Scan, Active”, you will then hear alerts for X, K, Ka-Band, and laser.

Wake-Up options can be changed in the Menu, page 22.

- Wake-Up Long: default and as described above.
- Wake-Up Short: default display sequence and an abbreviated audible sequence of three beeps.
- Wake-Up Silent: a display only sequence (no audible).

**GPS Connection** – After locating available satellites, the Platinum100 will announce, “GPS Connected”.

**NOTE:** *If you are in a location that prevents connection with GPS satellites (e.g. parking garage), your K40 will still alert you to all radar and laser threats (laser jamming only with optional Laser Defuser installed). Once you drive to an unobstructed location, the GPS will connect and you will hear, “GPS Connected”.*

**You’re ready to drive!** – Upon completion of the wake-up sequence, the default display will appear as follows:



**Want help customizing your Platinum100?  
Call a K40 Expert at 800.323.5608**

## Receiving Alerts


The Platinum100 provides a combination of audio and visual alerts to warn you when police radar and laser signals are detected.

### Radar Alert Sequence

The Platinum100 detects all North American police radar signals (X, K, and Ka-Band). When a signal is identified:

- The OLED display will provide you band and signal strength information. You can choose from a 5-bar alert display (default) or a 3-bar alert display. The alert indicators will display a range of colors from green when the signal is weakest to red when the signal is strongest.

#### Radar Alert Examples:



5-Bar Alert Display



3-Bar Alert Display

- A voice announces which radar band was detected (this assumes the factory default "Voice On" setting has not been changed).
- Signal strength and proximity to the radar source will be identified as a series of Geiger counter-like tones. The faster the tone pattern, the closer you are to the source. Each police radar band alert has its own distinctive tone.

## Laser Alert Sequence

When the Platinum100 detects a laser signal:

- The OLED display shows LASER and reports your speed.

**NOTE:** *Unlike radar, signal strength from laser remains constant.*

### Laser Alert Example:



- A voice announces, “Laser” (this assumes the factory default “Voice On” setting has not been changed).
- You will then hear a distinctive and urgent audio tone.

## Laser Defuser Compatible (sold separately)

Externally mounted K40 Laser Defuser transponders can connect to the Platinum100 to combat police laser guns. Contact your dealer for details.

## Laser Defuser Settings (if equipped)

Optional Laser Defuser(s) can be configured to one of three operational settings in the Menu (page 23):


Defuser Settings	Description	Recommended Use
<b>Constant Transmit</b>	For as long as the Laser Defuser is receiving a police laser gun signal, it will continuously transmit back to the gun. This is the factory default setting.  Alert Tone: standard laser alert tone.	<ul style="list-style-type: none"> <li>• Gives the driver more time to decelerate.</li> <li>• Higher potential for jamming all the way to the laser gun location.</li> </ul>

*(continued on following page)*



Defuser Settings	Description	Recommended Use
<b>Pulse Transmit</b>	<p>Upon receiving a police laser signal, the Laser Defuser will transmit a jamming signal for up to five seconds, then switches to <i>Receive Only</i> mode for 30 seconds.</p> <p>Alert Tones: standard laser alert tone for five seconds. Drops to a lower laser alert pitch tone in <i>Receive Only</i> mode.</p>	<ul style="list-style-type: none"> <li>• Gives you time to reduce speed. Officer will then be able to obtain speed to eliminate the suspicion of “jamming” where use of jammers is restricted.</li> <li>• Tone notifies you while a jamming signal is being transmitted and when Laser Defuser changes to <i>Receive Only</i>.</li> </ul>
<b>Receive Only</b>	<p>The Laser Defuser will only detect police laser. No jamming signal will be emitted.</p> <p>Alert Tone: lower pitch laser alert tone.</p>	<ul style="list-style-type: none"> <li>• For notification only. Officer will immediately obtain a speed reading on your vehicle in this setting.</li> </ul>

## — Manual Laser Defuser Shut Down During a Police Laser Encounter (if equipped)

Press and release  **button** to automatically switch the Laser Defusers to *Receive Only* for 30 seconds during a laser encounter. This gives you the option to control the duration of jamming signal being transmitted by the Laser Defusers.

## ———— Alerts from Non-Police Signals —————

Your K40 is sensitive enough to detect signals generated by non-police sources such as automatic doors, traffic flow sensors, and radar based safety features. To learn how to minimize non-police alerts, please read about TRAFFIC SENSOR FILTER (page 9), FILTER options (page 13), QUIET RIDE (page 14), and MARK TO MUTE (page 18).

## ————— K-Band Filter —————

Your K40 rejects alerts from most vehicles on the road equipped with radar-based safety features, such as collision avoidance. Police radar reception and detection range are unaffected by this feature.

————— **Traffic Sensor Filter** (factory default off) —————

Your K40 can reject alerts from traffic flow sensors usually encountered during highway driving (limited use areas). This feature can be enabled through the Menu (page 23).

— **MultaRadar (MRCD/CT) Photo Radar** (factory default off) —

Your K40 is capable of alerting to MRCD/CT photo radar devices (limited use areas). This feature can be enabled through the Menu (page 23).



————— **Auto Volume** (factory default on) —————

Your K40 will automatically reduce volume every three seconds until it reaches the “Low” setting. This feature can be disabled through the Menu (page 22).



## OLED DISPLAY Overview

### Display Color

Press and hold  button for three seconds to access the menu. Press and release the  button to scroll. Choose <<Color>> and select white (default), green, amber, red, or blue accents for the OLED display.


### Display Mode and Alert Options



Press and hold  button for three seconds to access the menu. Press and release  to scroll and choose <<Display>> for speed & compass or speed & voltage or speed & all-threat (Menu Page 22).

**Left:** Will always display your speed, either mph or kph.


**Center:** Optional clock while display is static. Otherwise blank until alert is detected; alert will display in this section.

**Right:** Option to display Compass (default), Voltage, or All-Threat.




For Alert Display Options, **Press and hold**  **button for three seconds** to access the menu. **Press and release**  to scroll and choose <<Alert Disp>> for 5-Bar (default) or 3-Bar alerts (Menu Page 22).

**5-Bar Alert** (Default) - During an alert, there are five available strength-of-signal bars that use the center and right section of the display.




**3-Bar Alert** - During an alert, there are three available strength-of-signal bars that use the center section only.



**M-Mute** means MARK TO MUTE function is active ...page 18.

**Band Frequency** Displays radar frequency being used.


**QR 20** means QUIET RIDE function is set at 20mph...page 14.



**All Threat Mode** Displays all alerts and the signal strength of each alert in the area. The strongest signal will appear in the center of the display and the other threats will appear on the right (3-bar alert is default if All Threat Mode is chosen).



## Dim Settings

Press and release  button to adjust and automatically save display brightness to accommodate various driving environments.

### Six Display Brightness Options:

1. **"Day"**- Brightest display setting.
2. **"Dusk"**- Medium display setting (factory default).
3. **"Night"**- Dimmest display setting.
4. **"Auto"**-Display adjusts automatically from three seconds in "Day," three seconds in "Dusk," and the duration of the alert in "Night".
5. **"Stealth"**-Display is dark with a single dot that scans the bottom of the display. Upon receiving a radar or laser signal, the display illuminates to medium brightness for the duration of the alert and then returns to dark when the alert ends.



6. **"Off"**-No display, still receive full audio alerts, reverts to "Auto" upon next wake-up.

## Special Features

### Highway|City|Filter|Auto

Press and Release  **button** to change the setting at any time. The **FILTER button** offers four levels of sensitivity to police radar signals to accommodate various driving situations.

Settings	Sensitivity	Recommended Use
<b>1. Highway</b> (factory default)	Maximum range and sensitivity on all North American police radar signals (X, K, and Ka-Band).	For highway travel or in any area in which you are unfamiliar with the types of radar used.
<b>2. City</b>	Decreases range and sensitivity on X, K, and Ka-Bands.	When traveling in an urban area with minimal non-police radar signals.
<b>3. Filter</b>	X-Band off. Further range and sensitivity reduction of K and Ka-Band.	When traveling in a congested traffic area with a high concentration of non-police radar signals.
<b>4. Auto</b>	Adjusts range and sensitivity on radar bands based on vehicle speed. 0-45 mph- <i>Filter</i> setting sensitivity. 46-55mph- <i>City</i> setting sensitivity. 56 mph+- <i>Highway</i> setting sensitivity.	Less sensitivity in low speed situations and more range and sensitivity in higher speed situations.

### K-Band Narrow|Wide|Extended

Select the range of police radar frequencies your K40 scans. This feature can be customized through the Menu (page 22).

- K Narrow scans the primary frequencies of police radar guns being used.

-Scans 24.080-24.200GHZ

- K Wide scans a little above and below the standard range of frequencies police radar guns can use. This is the factory default setting.

-Scans 24.026-24.285GHZ

- K Extended scans radar frequencies further below the standard range of speed enforcement technology that may be used in your area now or in the future.

-Scans 23.950-24.285GHZ

---

### **Ka-Band Narrow|Wide**

---

Select the range of police radar frequencies your K40 scans. This feature can be customized through the Menu (page 22).

- Ka Narrow scans the primary frequencies of police radar guns being used.

-Scans 33.7-33.9GHZ and 34.6-34.8GHZ  
and 35.4-35.6GHZ

- Ka Wide scans the entire possible range of frequencies police radar guns can use. This is the factory default setting.

-Scans 33.4-36.00GHZ

---

### **Ka-Band Filter**

---

Enables filtration of Ka-Band non-police radar signals, e.g. other radar detectors and satellite broadcast bands (factory default off). Use in high-traffic areas. Does not affect police radar detection range. This feature can be enabled through the Menu (page 23).

---

### **Quiet Ride**

---




The Quiet Ride function will automatically silence all radar and laser alerts when traveling under a speed selection of your choice between 5-75 mph in 5 mph increments, or 10-120 kph in 10 kph increments.

The display greys the alert received when driving under the chosen Quiet Ride setting.



The factory default setting for Quiet Ride is 20 mph (30 kph).

### Activating/Adjusting Quiet Ride:

- **Press and release**  **button** to activate the Quiet Ride menu. Voice will announce the current setting e.g. "Quiet Ride 20", or the current speed setting.
- **Press and release**  or  **button** to adjust the speed settings on Quiet Ride. Any selected speed setting indicates Quiet Ride is on.
- When you have made your desired Quiet Ride speed selection, stop scrolling and voice will announce, "Quiet Ride Set".



**NOTE:** Locations that you have "Marked to Alert" (page 19) are unaffected by Quiet Ride settings.

---

## Mute Functions

---

The K40 provides two options to mute audio alerts (both voice and tones):

- **Press and release**  **button** to mute audio for 30 seconds *or* the duration of the alert. Voice will announce, "Mute On", and display will show <<Mute On>>.
- **Press and hold**  **button** for three seconds to mute audio for five minutes. Voice will announce "Extended Mute On" and the display will show <<Ex-Mute On>>. Press and hold MUTE button for three seconds to turn Extended Mute off. \*

\* **NOTE:** You will only receive new alerts as visual indications on the display while this feature is engaged.



## Controls Overview

### Platinum100 Radar and Laser Detector

#### Windshield Mount Release

Press to release unit from windshield mount.

#### Speaker

Alerts delivered via voice and tones.

#### Defuser Input Jack

Connect optional Laser Defuser (page 24).

#### MARK Button

Press and release to mute specific radar/laser alerts in a location. Press and hold to mark specific locations for alert (pages 18-19).

#### MUTE Button

Press and release to mute audio for 30 seconds or the duration of the alert. Press and hold for 3 seconds to engage a 5-minute mute (page 15).

#### Mini-USB Port

Allows for future firmware updates.


#### QUIET RIDE/PWR Button

PWR-Press and release to power on. Press and hold for 3 seconds to power off (page 4).

Quiet Ride-Press and release to confirm speed setting and enter Quiet Ride menu (pages 14-15).

#### Windshield Mount

For proper installation see page 4.



#### Power Input Jack

Insert small end of power cord here. Large end plugs into 12V outlet (page 4).

#### FILTER/SM Button

Press and release to select level of alert sensitivity (page 13).

Press and hold to select a Speed Monitor setting (page 20).



#### Audio Jack

Allows alerts to be heard using an in-ear 8ohm speaker with 3.5mm jack.




#### DIM/MENU Button

Press and release to adjust display brightness (page 12). Press and hold for 3 seconds to enter Menu mode (page 21).

#### Volume Control

Adjust the volume up/down using  or  buttons.

#### To Set Preferences


Both  and  or  buttons are used to change settings.




## Mark to Mute

The **Mark to Mute** function allows you to mute any stationary radar band/laser alert from a non-police source (e.g. an automatic door) in a specific GPS location.

### Using Mark to Mute

- **Press and release**  **button** to mute a specific radar band/laser alert. A signal must be present in order to mark a location for mute.
- A voice announces that a specific radar band/laser alert has been muted (e.g. "K Muted").
- You will no longer receive audible alerts for the muted radar band/laser alert when within a 1,500 ft. radius of the muted location.
- You can string multiple muted locations together to extend the 1,500 ft. radius.
- You will still receive visual alerts from the display.
- <<M-Mute>> displays in the center section when within the muted location.



- All other radar bands/laser alerts remain unaffected.

### To remove individual muted locations from your database:

- **Press and release the**  **button** while in the marked location.
- Voice announces that a specific radar band/laser alert has been removed (e.g. "K Muted Removed").

## To remove ALL muted locations from your database:


1. **Press & hold**  **button** for three seconds to enter menu options.
2. **Press and release**  **button** until "Delete All Mute Locations" option is announced.
3. **Press & hold**  **button**. "All Muted Locations Cleared"

---



## Mark to Alert

---


The Mark to Alert function saves specific GPS locations to create a personal database of areas where increased awareness is desired, such as school zones, speed traps, or red light cameras.

- **Press and hold**  **button** when you want to mark a location for alert.
- Voice announces, "Marked to Alert".

In the future you will be alerted as follows:

When you arrive...	You will hear...
...within a radius of 1,500 feet of a marked location	..."Approaching Marked Location" and the display will show <<Mark 
...at a marked location	...a single "Bing" tone and the display will show <<Mark 

## To remove a previously marked location from your database:

- Press and hold  button for five seconds while in the marked location.
- Voice announces, "Marked Location Removed".

To remove all alert locations, follow Steps 1-3 on Page 19, but on Step 2, select the "Delete All Alert" option instead.




---

## Speed Monitor

---

Speed Monitor alerts when a preselected speed is exceeded. Speed Monitor can be set to any speed between 40-100 mph in 5 mph increments or 60-160 kph in 10 kph increments. The factory default setting for Speed Monitor is "Off".

### Activating/Adjusting Speed Monitor:

- Press and hold  button for three seconds. Voice announces "Speed Monitor".
- Press and release  or  buttons to select the desired maximum speed for alerts.
- The voice will announce "Speed Monitor Set", the display will return to the main screen, and your speed setting will be saved.

### When driving and the Speed Monitor speed is exceeded:






- The Platinum100 emits a continuous "Bing Bong" tone accompanied by the visual display <<Slow Down>>.
- The alerts will continue until the vehicle's speed is reduced to below the Speed Monitor setting.




## Customizable Settings

To change the factory preset features and customize your Platinum100 for the way you drive, follow the instructions below or call a K40 Consultant at 800.323.5608.

### To change settings:

- **Press and hold**  **button** for three seconds. The voice will announce "Menu", and the display will read <<MENU>>.
- **Press and release**  **button** to scroll through the options in the order listed on the following page. Continue until you reach the option to be changed.
- **Press and release**  **or**  **button** to change a setting. Both the display and voice will announce the change.
- **Press and release**  **button** to continue scrolling to another option.

### To save your settings and exit:

- **Press and hold**  **button** for three seconds or wait ten seconds, and the system will automatically save your preferences.
- The voice will announce "Exit" and the display will show <<Exit>>.

<b>Menu Options</b> (in order displayed)		<b>Default Setting</b>	<b>Description</b>
1	Voice Type	Female	Choose male or female voice for audio alerts.
2	Audible Voice	On	For all initial audio alerts: "Voice On" uses voice; "Voice Off" uses tones only.
3	Wake-Up Sequence	Wake-Up Long	<ul style="list-style-type: none"> <li>•"Wake-Up Long" is a standard 5 second sequence.</li> <li>•"Wake-Up Short" uses an abbreviated sequence.</li> <li>•"Wake-Up Silent" display only, no audible.</li> </ul>
4	Auto Volume	On	Automatically reduces volume every 3 seconds.
5	Display Color	White	Choose white, red, blue, amber, or green accents for OLED display.
6	Display Mode	Speed/Compass	Speed/Compass, Speed/Voltage, Speed/All Threat on left and right of display.
7	Alert Display	5-Bar	5-bar or 3-bar alert display setting.
8	Time	Off	Enable to see a clock in the center section of the display.
9	DST	Off	Enable Daylight Savings Time.
10	GMT	-5	<p>Sets time zone according to Greenwich Mean time (GMT). Common North American time zone settings:</p> <ul style="list-style-type: none"> <li>•GMT - 05:00 - Eastern Standard</li> <li>•GMT - 06:00 - Central Standard</li> <li>•GMT - 07:00 - Mountain Standard</li> <li>•GMT - 08:00 - Pacific Standard</li> <li>•GMT - 09:00 - Yukon Standard</li> <li>•GMT - 10:00 - Alaska-Hawaii Standard</li> </ul>
11	X-Band	On	Enables the detection of X-Band radar.
12	K-Band Selectivity	Wide	<ul style="list-style-type: none"> <li>•K Wide scans the standard range of K-Band frequencies that police radar guns can use.</li> <li>•K Narrow scans the primary K-Band frequencies of police radar guns being used.</li> <li>•K Extended scans radar frequencies above and below the standard range of speed enforcement technology that may be used in your area now or in the future.</li> </ul>
13	Ka-Band Selectivity	Wide	<ul style="list-style-type: none"> <li>•Ka Wide scans the entire possible range of Ka-Band frequencies that police radar guns can use.</li> <li>•Ka Narrow scans the primary Ka-Band frequencies of police radar guns being used.</li> </ul>

<b>Menu Options</b> (in order displayed)		<b>Default Setting</b>	<b>Description</b>
14	Ka Band Filter	Off	Enables filtration of Ka-Band non-police radar signals.
15	Traffic Sensor Filter	Off	Enables filtration of K-Band signals from traffic flow radar sensors to reduce false alerts.
16	MRCD/CT	Off	Enables MRCD/CT photo radar detection.
17	MRCD/CT Filter	Off	Reduces false alerts when MRCD/CT detection is enabled.
18	Laser	On	Enables the detection of Laser.
19	Optional Defuser	Off	Enables the Laser Defuser.
20	Laser Settings	Constant	Choose Constant, Pulse, or Receive transmit mode of the K40 Laser Defuser system.
21	Speed Units	mph	Choose miles per hour or kilometers per hour.
22	Low Battery	Off	Warning tone sounds if vehicle battery power drops below 11V.
23	Auto Power	Off	Turns power off if speed stays at zero or if GPS not connected for one hour.
24	Mute Locations	N/A	Clears all stored muted locations. See page 19.
25	Alert Locations	N/A	Clears all stored alert locations. See page 20.
26	Firmware		Current firmware version.
27	Factory Reset	Reset	Original Factory default settings.
	"EXIT"	"EXIT"	Exit the settings menu and save your selections.

## Add-On Options

(sold separately)

### Wireless Remote Control

---

System control in the palm of your hand with K40's wireless, keyfob size remote control. Can also be mounted to your visor with supplied clip for convenient access.



### Expert Remote Controller

---

System control at your fingertips with a professionally installed, backlit control, designed to look like it was factory installed.



### Laser Defusers

---

Combat police laser threats by integrating K40 Laser Defusers. Defusers are professionally installed, externally mounted laser jammers.




### External Mute Button

---

Access to full mute button functions, including Defuser shut down, with a professionally installed mute button in an easy to reach location of your choosing.



# Wireless Remote Control Functions



## Troubleshooting Guide

Need some help? Call us at 800.323.5608 for assistance and to customize your settings.

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
<b>No visual display or audio</b>	Power not inserted properly.	Confirm power cord is inserted into opening closest to windshield with the center pin.
	Blown fuse in power cord.	Replace fuse with 2 amp 250 Volt F2AL fuse.
	12V outlet not clean or negatively grounded.	Consult your K40 dealer.
	Defective fuse or electrical wiring for 12V outlet.	Consult your K40 dealer.
<b>Weak or no detection range</b>	Partially blocked antenna or lens opening.	Reposition to ensure unobstructed view of the road ahead.
	Radar/laser signals unable to pass through windshield.	Determine if your vehicle has a heated windshield or is covered with a metallic tint. Check your vehicle's owner's manual or consult with your dealer.
<b>Erratic or frequent alerts</b>	High concentration of non-police radar sources.	Check Filter Mode (page 13), Quiet Ride (pages 14-15), Traffic Sensor Filter (page 9) MRCD (page 9) settings.
<b>Mount not sticking to windshield</b>	Suction cup surface requires cleaning.	Warm water and dish soap. Wipe with your fingers and rinse. Air dry No towels.



## Warranty/Guarantees



### **One-Year Warranty**

The K40 Platinum100 Portable Radar/Laser Detector is covered by a one year "repair or replace" limited warranty. This coverage begins on date of purchase and applies to manufacturing defects in product materials and workmanship only. Installation, removal, or misuse is not covered.

### **Guaranteed Performance**

If your K40 does not outperform any other radar detector you've owned, return it within 30 days for a full product credit.

### **Guaranteed Immunity from Speeding Tickets**

Get a ticket, K40 will pay it. Subject to the terms and conditions below. Simply send us a copy of the radar or laser speeding ticket, your proof of payment of the ticket, and your receipt for your K40 purchase.

To ensure you are covered by these guarantees, please register your K40 within 30 days of purchase date via the included warranty registration card or online at **K40.com**

### **Terms and Conditions:**

Ticket-Free Guarantee not valid for tickets issued in school or construction zones, incurred with a DUI or DWI violation, or for tickets received outside the U.S. and Canada.

In Canada—excludes any photo radar/laser and/or any tickets issued that do not accumulate demerit points.

Product subject to one or more of the following patents:

U.S. Patents 5,001,777

RE39,038

RE40,653

RE41,905

Other patents pending

**Learn more at [K40.com](http://K40.com)**

©K40 Electronics

**FCC ID: W75-D-Y10**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

In addition, any changes or modifications to this product, which are not expressly approved by K40 Electronics in writing, could void the user's authority to operate this product.





## **Our Promise**

### **To Exceed...**

Customer expectations through the pride and dedication of our strong team of caring and talented employees by being the “Model of Excellence” in the entire industry on every level — from innovative product design and flawless manufacturing to knowledgeable sales and total customer service.

### **To Provide...**

The most superior and progressive radar detectors and laser jamming solutions on the worldwide market with guaranteed performance by delivering tomorrow’s solutions today through the most advanced technology systems and state-of-the-art radar detection defense.

### **To Ensure...**

The total commitment of our entire staff to all customers before, during, and after the sale with personalized direct 24/7 customer support — and going the extra mile with product selection and usage assistance in step with individual needs to achieve the most dependable radar detection performance and success.



## Letter From the President

Thank you very much for your recent purchase of the most progressive radar and laser solution available on the market today.

Our mission is to empower you, our valued customer, with peace of mind and unparalleled radar protection.

Because we care about you, we've stood behind every product for over 40 years with the industry's first speeding ticket guarantee. If you get a ticket, we pay for it! That's right, guaranteed!

Whether you are a first-time customer or a lifelong friend, we sincerely appreciate your confidence. We'll always go that extra mile to provide you with what's new, and the latest in leading-edge radar and laser technology.

Our products are detailed and customized to specifically serve the needs of every vehicle and driver. We promise you that there never is a cookie-cutter approach here.

Again, thank you for your business. Your safety and protection is what we're all about!

Sincerely,



Peggy Finley  
*Owner/President*



The background of the entire page is a dark, atmospheric scene featuring a grid of bright white laser lines that recede into the distance. In the background, the silhouettes of several skyscrapers are visible against a twilight sky. The overall aesthetic is high-tech and futuristic.

**K40**<sup>™</sup>  
ELECTRONICS

Elgin, IL 60123 800.323.5608

44915- 7/20



## Please complete and retain this portion for future reference.

**If you get a radar or laser speeding ticket, we'll pay for it.** That's how confident we are about the technology that's built into your new K40.

***This warranty is in effect for up to one full year from the date of your purchase. For speeding ticket reimbursement, simply follow these steps:***

1. Your Ticket-Free Warranty Card (below) must be sent to us for registration prior to receiving a speeding ticket. You may also register online at K40.com.
2. When applying for reimbursement, you must send us a copy of your proof of purchase (a dated sales receipt) for your K40.
3. Include a copy (not the original) of the speeding ticket. The speeding ticket or court receipt must say "for radar or laser speeding" or provide other proof that radar or laser was involved.
4. Send proof of speeding ticket payment. Either a copy of a cancelled check (both sides), money order, or court receipt.
5. Mail these items to: **K40 Electronics**,  
600 Tollgate Rd., Suite A, Elgin, Illinois 60123.
6. Your Ticket-Free Warranty excludes tickets issued in school zones, construction zones, incurred with a DUI or DWI violation, or for tickets received outside the U.S. and Canada.
7. In Canada: Excludes any photo radar/laser and/or any tickets issued that do not accumulate demerit points. (Portable radar only)



**Any questions/comments? Call us! 800-323-5608**

K40 Model

Purchased From

Date Purchased

City

State

# Ticket-Free Warranty Registration

**IMPORTANT:**

*In order to process speeding ticket reimbursement claims, the form below must be fully completed. Please print clearly—all information will remain confidential. You may also register online at **K40.com***

Full Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ ZIP \_\_\_\_\_

Email Address \_\_\_\_\_ Daytime Phone \_\_\_\_\_

Vehicle Description:

\_\_\_\_\_ (Year) \_\_\_\_\_ (Make) \_\_\_\_\_ (Model)

Authorized K40 Dealer Name \_\_\_\_\_ ZIP \_\_\_\_\_

Radars	Laser
Platinum360	Laser Defuser(s)
Platinum200	_____ How many?
Platinum100	

Total Price Paid \$ \_\_\_\_\_ Purchase Date \_\_\_\_\_

Additional Comments: \_\_\_\_\_

Please contact me to discuss extending my Ticket-Free warranty.  
*(Offer available only to K40 owners residing in the U.S.)*



## Warranty Registration for Ticket-Free Driving

Mail this Registration Card *immediately!*  
Or, complete online at **K40.com**

- Registration card *must be submitted* within 30 days of purchase to register you in the K40 Ticket-Free Guarantee Program. You can register by mail or online at **K40.com**. If you get a radar or laser speeding ticket, we'll pay for it. (Details on other side.)
- Your K40 guarantee excludes tickets issued in school zones, construction zones, and/or when DWI or DUI is involved.
- Speeding ticket reimbursement claims will **not** be considered if registration is not completed and received by K40 within 30 days of purchase.

**K40**<sup>TM</sup>  
ELECTRONICS

---

---

---

PLEASE PLACE  
FIRST CLASS  
STAMP HERE



600 Tollgate Road Suite A  
Elgin, IL 60123